


JUKI DDL 系列 AK34/35/84/85 移位裝置安裝手冊 NO. AK35

# INSTALLATION MANUAL OF JUKI DDL SERIES AK34/35/84/85 RELOCATION ASSEMBLY




## 準備動作 ADVANCE WORK

拆下 AK 裝置框內零件  
PLEASE TAKE APART THE PARTS FOR  
AK DEVICE WHICH INSIDE OF LINE




## AK 移位組 組合圖 ASSEMBLE ILLUSTRATION FOR AK RELOCATION ASSEMBLY



## 壓腳提升量調整

## ADJUST AUTO-LIFTER



## 零件圖

## PARTS ILLUSTRATION

